

CoolMasterNet PRM



CoolMasterNet Universal Interface Adapter for HVAC Systems





Attention

1. During the HVAC system automatic operations the CoolMasterNet must be disconnected from the system.

Examples of the automatic operations are:

- Test
- Reset
- Automatic charge

2. Do not change the original positions of the quadruple dip switch S inside CoolMasterNet when using it with VRV/VRF systems.

WEEE Directive & Product Disposal



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

Table of Contents

1 Document Revision History	5
2 Acronyms	6
3 Layout	7
4 Connections	8
4.1 HVAC Lines	8
4.2 HomeAutomation/BMS Protocols.....	8
4.3 RS232 Port	9
4.4 Ethernet	9
ASCII I/F IP Server	10
Modbus IP	10
CoolRemote cloud connection	10
4.5 RS485	11
ModBus RTU	11
CG4	11
CG5	11
HDL buspro	11
4.6 GPIO	11
4.7 USB	12
4.8 Power	12
5 DIP Switches	13
6 ASCII I/F	15
6.1 General Protocol Definitions.....	15
Messaging	15
Exit Code	15
UID	17
6.2 Commands Reference.....	18
Configuration Commands	19
set	19
line	20
ifconfig	22
boot	23
sddp	23
knx	24
props	26
link	27
plug	28
ad	28

hdl	29
simul	30
gpio	30
info	32
modbus	32
HVAC Status and Control Commands	33
on	34
allon	34
off	35
alloff	35
cool	35
heat	36
fan	36
dry	36
auto	37
temp	37
feed	39
fspeed	40
swing	41
filt	41
stat	42
ls	42
ls2	43
query	44
wh	45
main	46
vam	47
lock	48
inhibit	49
group	49
va	50
istat	51
ostat	52



1 Document Revision History

0.9

- ad command
- inhibit command
- added Bluestar

0.8

- feed command rework
- Added UID for 4-digit systems and HT
- CoolRemote connection

0.7

- Added Haier

0.6

- Added Chigo

0.5

- Added Midea, Kentatsu, Trane, Fujitsu

0.4 - Initial




0.3 - Preliminary



2 Acronyms

DTE	Data Terminal Equipment
ETH	Ethernet
GPIO	General Purpose Input/Output
HVAC	Heating Ventilation and Air Conditioning
TBD	To Be Defined

3 Layout



1. USB Host, HVAC Line L8
2. Power
3. Power Plug
4. RS232 Port
5. HVAC Line L1
6. HVAC Line L2
7. HVAC Line L3 or RS485 Port
8. Ethernet Port
9. GPIO
10. HVAC Line L7
11. HVAC Line L6
12. HVAC Line L5
13. HVAC Line L4
14. USB Device Port
15. DIP Switches P,Q, R,S
16. LCD with Touch Screen

4 Connections

4.1 HVAC Lines

CoolMasterNet supports eight HVAC Lines labeled as **L1 ... L8** (see [Layout](#)), intended for connection to various HVAC systems. All eight HVAC Lines can be used simultaneously (except **L1** with **L5** and **L2** with **L6**) and independently according to CoolMasterNet configuration. Most of the HVAC Lines capable to support a number of HVAC Types as specified in table below, but one at time, according to configuration of the specific Line.

HVAC Manufacturer	Acronym	L1	L2	L3	L4	L5	L6	L7	L8
Daikin	DK	✓	✓						
Mitsubishi Electric	ME	✓	✓						
Sanyo	SA	✓	✓						
Toshiba	TO	✓	✓						
Panasonic	PN	✓	✓						
Hitachi	HT	✓	✓						
LG	LG			✓	✓	✓	✓	✓	
Mitsubishi Heavy Industries	MH			✓	✓	✓	✓	✓	
Gree	GR			✓	✓	✓	✓	✓	
Midea	MD			✓	✓	✓	✓	✓	
Kentatsu	KT			✓	✓	✓	✓	✓	
Trane	TR			✓	✓	✓	✓	✓	
Chigo	CG			✓	✓	✓	✓	✓	
Fujitsu	FJ								✓
Samsung	SM			✓	✓	✓	✓	✓	
Tadiran Inverter	TI			✓	✓	✓	✓	✓	
Meitav	MT			✓	✓	✓	✓	✓	
Haier	HA	✓	✓						
Bluestar	BSM			✓	✓	✓	✓	✓	

Notes:

- [DIP Switches Q](#) and [R](#) are used to adjust lines **L1** and **L2** internal parameters to meet specific HVAC Type requirements.
- Lines **L1** and **L5** share the same internal resources of CoolMasterNet and can not be used simultaneously.
- Lines **L2** and **L6** share the same internal resources of CoolMasterNet and can not be used simultaneously. [DIP Switch P3](#) defines which line is enabled.
- Lines **L6** and **L7** can be linked into a single line **L7** with polarity auto-detection, by [DIP Switches P1](#) and [P2](#). Line **L2** can be enabled in this case.
- Line **L3** is by default used for ModBus RTU RS485 communication.

4.2 HomeAutomation/BMS Protocols


CoolMasterNet supports several Home Automation/BMS protocols.

Home Automation/BMS Protocol	Acronym	Line(s)/Port
KNX	KNX	L3
PlugBus (CoolHub)	CH	L3,L4,L5,L6,L7

HDL buspro 4-wire	HDL	L3,L4,L5,L6,L7
HDL buspro IP		Ethernet
ModBus RTU CoolGate 4	CG4	L3,L4,L5,L6,L7
ModBus RTU CoolGate 5	CG5	L3,L4,L5,L6,L7
ModBus IP		Ethernet
SDDP		Ethernet
ASCII I/E		RS232, Ethernet
CoolRemote		Ethernet

4.3 RS232 Port

RS232 Interface on CoolMasterNet is available from the RS232 DB9 female connector. Below is a DB9 connector front view and signals table.



DB9 Pin	Signal Level	Description
2	±12V	TxD (Data from CoolMasterNet to DTE)
3	±12V	RxD (Data from DTE to CoolMasterNet)
5	GND	Ground
1,4,6,7,8	Not Connected	

Gender and pinouts of the RS232 cable supplied with CoolMasterNet are suitable for connection to PC RS232 port directly or via standard RS232 to USB adapter. Maximal length of the RS232 Cable should not exceed 25m. By default RS232 Interface is dedicated for [ASCII I/E](#). The default CoolMasterNet RS232 Port settings are:

Baud Rate	9600
Data Bits	8
Parity Control	None
Stop Bits	1
Flow Control	None

4.4 Ethernet

CoolMasterNet incorporates an IEEE 802.3 compatible 10/100 Mb/s Ethernet port supported via RJ45 connector. Below are main port features.

Parameter	Value	Notes
-----------	-------	-------

Max Ethernet Cable Length	137m	CAT5 twisted pair cable
Bit Rate	10/100 Mb/s	
Supported Ethernet Protocols	10BASE-T/100BASE-TX	
Protocol Auto-Negotiation	Enabled	Against Link Partner

RJ45 connector comprises Link and Activity indication LEDs providing following statuses.

LED	Color	Function
Link Led	Green	ON for good link OFF for no link
Activity Led	Orange	BLINK for Tx/Rx Activity

Ethernet port is used by a number of protocol modules available in CoolMasterNet

- ASCII I/F (via [ASCII I/F IP Server](#))
- [ModBus IP](#)
- HDL buspro IP
- SDDP
- CoolRemote

Network setting of the CoolMasterNet are controlled with [ifconfig](#) command.

4.4.1 ASCII I/F IP Server

ASCII I/F IP Server referenced as **aserver** is a classic row TCP/IP socket server. Aserver has following default characteristics:

Maximal number of simultaneous connections	4
Default TCP/IP port	10102
Prompt character >	enabled





Aserver can be configured with [set](#) command.

4.4.2 Modbus IP

See [Modbus Integration Guidelines](#) document.

4.4.3 CoolRemote cloud connection

CoolMasterNet is constantly maintaining connection with CoolRemote cloud server once TCP/IP networking with internet access is established. CoolRemote connection status is displayed on LCD screen by the cloud icon in bottom right corner of the screen.

	No TCP/IP Networking
	Connected - Idle
	Connected - Communicating
	Disconnected - with error code

4.5 RS485

By default Line **L3** is used as an RS485 Interface line for **DTE** connection. CoolMasterNet supports the following RS485 based protocols:

- [ModBus RTU](#) (Slave mode)
- HDL buspro

4.5.1 ModBus RTU

CoolMasterNet can be used as a ModBus RTU slave device working in accordance with [Modbus-IDA.ORG](#) "MODBUS over serial line specification and implementation guide". RS485 default frame format is

Baud Rate	9600
Data Bits	8
Parity Control	None
Stop Bits	1
Flow Control	None

4.5.2 CG4

CG4 is based on ModBus RTU protocol. Its address map is similar to CoolGate device, previously manufactured by CoolAutomation (see CoolGate PRM for more information). CG4 protocol can be used for backward compatibility.

4.5.3 CG5


See [Modbus Integration Guidelines](#) document.

4.5.4 HDL buspro

See [HDL Integration Guidelines](#) document.

4.6 GPIO

CoolMasterNet supports four GPIO marked as **A B C D** (see [Layout](#)). GPIO can be in Input or Output mode depending on it's functionality



Parameter	GPIO A	GPIO B	GPIO C	GPIO D
Input Low Voltage (V _{IL})	<1V	<1V	<1V	ADC
Input High Voltage (V _{IH})	>2.4V	>2.4V	>2.4V	ADC
Output High Voltage (V _{OUT HI})	3.3V	3.3V	3.3V	3.3V
Max Output Current (I _{OUT})	20mA	20mA	20mA	20mA
Pull Up	5.6K	5.6K	5.6K	N.A.

Control of the GPIO functionality is done with [gpio](#) command.

4.7 USB

CoolMasterNet incorporate USB Device and USB Host ports. USB Device port is used for maintenance operations.


4.8 Power

CoolMasterNet can be powered from different power sources:

- AC/DC adapter supplied with CoolMasterNet
- 12-24V DC from HVAC or other equipment
- USB Device port

5 DIP Switches

DIP Switches are located behind the small access door at the upper right side of the CoolMasterNet.



DIP Switch P

Switch	ON	OFF
P1,P2	Link L6,L7 and enable polarity auto-detection on L7	Separate L6,L7
P3	L6 Enabled, L2 Disabled	L2 Enabled, L6 Disabled
P4	Production Mode	Normal Operation Mode

Notes:

- Switches P1 and P2 should be in the same position. If they are both in ON position, HVAC Lines L6 and L7 are linked into one line with option to auto-detect line polarity. Otherwise, if both P1 and P2 are in OFF position HVAC Lines L6 and L7 are separate independent lines.
- If L6 and L7 are linked into L7, enabling of the L2 with P3 will not influence on L7 operation.
- Switch P4 must be in OFF position for normal operation of CoolMasterNet.

DIP Switches Q,R

DIP Switched Q and R are used to adjust HVAC Lines L1 and L2 internal parameters to meet specific HVAC type requirements.

HVAC Type	DIP Switch Q - HVAC Line L1			
	Q1	Q2	Q3	Q4
DK	ON	OFF	ON	OFF
ME	OFF	OFF	OFF	OFF
TO	OFF	ON	OFF	ON
SA	OFF	ON	OFF	ON
PN	OFF	ON	OFF	ON
HT	OFF	ON	OFF	ON
HA	OFF	ON	OFF	ON

HVAC Type	DIP Switch R - HVAC Line L2			
	R1	R2	R3	R4

DK	ON	OFF	ON	OFF
ME	OFF	OFF	OFF	OFF
TO	OFF	ON	OFF	ON
SA	OFF	ON	OFF	ON
PN	OFF	ON	OFF	ON
HT	OFF	ON	OFF	ON
HA	OFF	ON	OFF	ON

Notes:

- If all four Dip Switches R1, R2, R3, R4 are in ON position during CoolMasterNet power reset, CoolMasterNet will be forced to enter BOOT Mode.

Dip Switch S

Switch	ON	OFF
S1,S2	Enable DC Output on HVAC Line L1	Disable DC Output on HVAC Line L1
S3,S4	Enable DC Output on HVAC Line L2	Disable DC Output on HVAC Line L2

Notes:

- Switches S1 and S2 should be in the same position.
- Switches S3 and S4 should be in the same position.
- DC Output on HVAC Line L1 or L2 is required only in case when the line is configured as DK or ME and non VRF equipment is connected to this line (via KRP, MAC or similar adapter). **And only if no other DC source is present on this line.**

6 ASCII I/F

CoolMasterNet provides a simple and comprehensive ASCII I/F Protocol, based on text (ASCII) strings, representing verbal commands and responses. ASCII I/F implemented in CoolMasterNet is fully backward compatible with previous versions of CoolAutomation products, but has a number of significant extensions and improvements mainly aimed to support additional CoolMasterNet functionality. ASCII I/F can be utilized via RS232 interface (see [RS232 Port](#)) or TCP/IP [Server](#).

6.1 General Protocol Definitions

6.1.1 Messaging

Communication between DTE and CoolLinkNet via ASCII I/F is based on text (ASCII) strings. Communication example is shown below

>ls L2	←command	DTE to CoolLinkNet
L2.102 OFF 20C 27C Auto Cool OK - 0	←response	CoolLinkNet to DTE
L2.103 OFF 20C 24C Low Auto OK - 0	←exit code	
OK	←prompt	
>		

Command string sent to CoolLinkNet must be terminated with <CR> (carriage return 0x0D) <LF> (line feed 0x0A) sequence or a single <CR> character. Strings from CoolLinkNet (except prompt character) are always terminated with <CR> <LF>. Commands are case sensitive and should not contain leading or trailing spaces. The only separator between command name and command parameter(s) is space (0x20) character. Configuration parameter **echo** (see [set](#) command), defines if characters sent to CoolLinkNet via [RS232 interface](#) are echoed back or not. If **echo** is not zero - characters are echoed.

In case of RS232 interface, prompt character '>' is unconditionally sent by CoolLinkNet. In case of [ASCII Server](#) prompt sending is configurable.

6.1.2 Exit Code

CoolMasterNet provides Exit Code in verbose or numeric form. Numeric form format is

ERROR : N

where N is a number in range 0...999. If verbose format is not specified in table below it means error has only numeric format.

Numeric	Verbose	Description
0	OK	Command executed successfully
1	No UID	UID not found
2	Not Strict UID	UID must be precise
3	Bad Format	Command format is wrong
4	Failed	Command execution failed
5	Line Unused	Line is unused
6	Unknown Command	Command is unknown
7	Bad HVAC Line	Line number is wrong
8	Bad Function	Wrong function
9	Bad Line Type	Wrong line type definition
10	Bad Parameter	Command parameter is wrong
11	OK, Boot Required!	Command execution will be effective after reboot
12	Bad GPIO	Wrong GPIO

13	SDDP Disabled	SDDP module is disabled, enable it to proceed
14	Virtual Address In Use	Virtual address already in use
15	Bad Property	Wrong property
16	Number of lines exceeded	Can't define more line types
17	Warning! Dip Switch State Incorrect	Dip switch state is incorrect for defined line type
18	SDDP Not Initialized	SDDP is enabled, but Ethernet link is still down
80	ModBus Error:80	No response from the addressee
81	ModBus Error:81	Big timeout between bytes in received message
82	ModBus Error:82	Small timeout between bytes in received message
83	ModBus Error:83	Received message with internal timeout
84	ModBus Error:84	Received message is too big
85	ModBus Error:85	CRC error in received message
86	ModBus Error:86	ModBus exception in response
100	Collision	Collision in sent command on HVAC line
101	Unsupported Feature	Unsupported command or command's parameter for this HVAC line
102	Incorrect Indoor Type	Chosen Indoor Unit doesn't support this command or command's parameter
103	No ACK From Indoor	Indoor Unit didn't acknowledged sent command
104	Time Out on Receive	No response from Indoor Unit
105	CS Error In Received Message	Check Sum error in received message
106	Line Init In Progress...	Can't show lines status due to initialization process
107	Line Error	Some error on the HVAC line
108	Feed Disabled	Indoor Unit can't receive measured ambient temperature due to its switch position
150	HDL Not Initialized	HDL line was not defined or ethernet cable is unplugged
151	HDL DB Overflow	HDL Data Base is full, can't add new configuration
152	HDL Eth Disabled	HDL over ethernet disabled
200	UID Not Found	Specified Indoor Unit not found in Data Base
201	Strict UID Not Found	Specified Indoor Unit by uid strict not found in Data Base
202	Indoor Removed	Indoor Unit removed from Data Base
203	DB Overflow	Indoor Units Data Base is full, can't add new one
204	Group DB Overflow	Group Data Base is full, can't add new group
205	VA DB Overflow	Virtual address Data Base is full, can't associate Indoor Unit with new virtual address
206	FDB5 Overflow	Properties Data Base is full, can't add new property
250	Link DB Overflow	Link Data Base is full, can't link new CoolPlug device with Indoor Unit
251	No CoolHub Line	CoolHub line not defined, define it to proceed
252	Auto Visibility Failed	During link creation there was an error on adding visibility props
253	Link already exists	CoolPlug device already linked, delete previous link before creating the new one
307	KNX DB Overflow	KNX Data Base is full, can't add new group
309	KNX Not Connected	No connection with KNX chip
310	KNX Line Not Started	KNX line not defined

6.1.3 UID

UID is used to identify Indoor Unit or a set of Indoor Units. UID has the following format:

Line number	Dot	Indoor number	
Ln	.	X	YY

- Line is a CoolMasterNet HVAC Line number like L1, L2,... L* means "any line". To provide backward compatibility with CoolMaster or CoolLink devices, Line number can be omitted from the UID.
- Dot is a separator between Line number and Indoor number. If Line number is omitted or has a L* form, dot must also be omitted.
- Indoor number is an Indoor Unit number in HVAC system. Indoor number can be "*" that means "any"

Examples:

L1.102	Indoor Unit 102 on line L1
L2.003	Indoor Unit 003 on line L2
L*100	Set of Indoor Units 100 on all lines
L3.1*	Set of Indoor Units 1xx on line L3 (L3.100, L3.101, ...)
L4	All Indoors on line L4
L*	All Indoors on all lines
203	Similar to L*203 (for backward compatibility only)

UID_STRICT

In some cases only specific Indoor Unit had to be referenced by UID. In this case it is required to use UID_STRICT in format Ln.XYY where '*' usage is prohibited.

HVAC systems with 4-digit Indoor unit numbers

For HVAC systems with 4-digit Indoor unit numbers: N1N2 - N3N4, the first two digits N1 N2 in range 00-15, will be encoded into X part of the UID according to the following table. The last two digits N3 N4 will be equal to YY part of the UID.

N1N2 - N3N4	X YY	Example for line L1	
		Indoor Unit number	UID
00 - N3N4	0 N3N4	00-12	L1.012
01 - N3N4	1 N3N4	01-12	L1.112
02 - N3N4	2 N3N4	02-12	L1.212
03 - N3N4	3 N3N4	03-12	L1.312
04 - N3N4	4 N3N4	04-12	L1.412
05 - N3N4	5 N3N4	05-12	L1.512
06 - N3N4	6 N3N4	06-12	L1.612
07 - N3N4	7 N3N4	07-12	L1.712
08 - N3N4	8 N3N4	08-12	L1.812
09 - N3N4	9 N3N4	09-12	L1.912
10 - N3N4	A N3N4	10-12	L1.A12
11 - N3N4	B N3N4	11-12	L1.B12
12 - N3N4	C N3N4	12-12	L1.C12
13 - N3N4	D N3N4	13-12	L1.D12
14 - N3N4	E N3N4	14-12	L1.E12
15 - N3N4	F N3N4	15-12	L1.F12

Besides generic UID encoding rules, described above, there are special rules applicable for specific HVAC systems.

UID encoding for Hitachi (HT) HVAC system

HT Indoor Unit number		UID for line L1
RN	ADDR	
00	00 - 63	L1.000 - L1.063
01	00 - 63	L1.100 - L1.163
02	00 - 63	L1.200 - L1.263
03	00 - 63	L1.300 - L1.363
04	00 - 63	L1.400 - L1.463
05	00 - 63	L1.500 - L1.563
06	00 - 63	L1.600 - L1.663
07	00 - 63	L1.700 - L1.763
08	00 - 63	L1.800 - L1.863
09	00 - 63	L1.900 - L1.963
10	00 - 63	L1.A00 - L1.A63
11	00 - 63	L1.B00 - L1.B63
12	00 - 63	L1.C00 - L1.C63
13	00 - 63	L1.D00 - L1.D63
14	00 - 63	L1.E00 - L1.E63
15	00 - 63	L1.F00 - L1.F63
16	00 - 35	L1.064 - L1.099
17	00 - 35	L1.164 - L1.199
18	00 - 35	L1.264 - L1.299
19	00 - 35	L1.364 - L1.399
20	00 - 35	L1.464 - L1.499
21	00 - 35	L1.564 - L1.599
22	00 - 35	L1.664 - L1.699
23	00 - 35	L1.764 - L1.799
24	00 - 35	L1.864 - L1.899
25	00 - 35	L1.964 - L1.999
26	00 - 35	L1.A64 - L1.A99
27	00 - 35	L1.B64 - L1.B99
28	00 - 35	L1.C64 - L1.C99
29	00 - 35	L1.D64 - L1.D99
30	00 - 35	L1.E64 - L1.E99
31	00 - 35	L1.F64 - L1.F99

6.2 Commands Reference

Synopsis and description of the commands listed below have the following notation:

- Parameters or parameters group in angle brackets < > are mandatory.
- Parameters or parameters group in square brackets [] are optional and can be omitted.
- The curly braces () are used to denote group inside braces
- The | character between parameters inside brackets means OR.

6.2.1 Configuration Commands

[set](#)
[line](#)
[ifconfig](#)
[boot](#)
[props](#)
[link](#)

[simul](#)
[gpio](#)
[info](#)
[modbus](#)
[ad](#)

[plug](#)
[knx](#)
[hdl](#)
[sddp](#)
luxom

set

SYNOPSIS

```
set [<SETTING> <VALUE>]
set defaults
```

DESCRIPTION

Query or change CoolMasterNet setting(s). Without parameters **set** command will list all supported settings and their values. To change setting use format with **<SETTING>** and **<VALUE>**. Some settings are read only (RO) and can not be changed.

set defaults will load default values to all settings

<SETTING>	Mode	Printed as	Value*	Description
S/N	RO	S/N		CoolMasterNet Serial Number
version	RO	version	X.Y.Z	CoolMasterNet Firmware Version
app	R/W	application	string	CoolMasterNet Application
baud	R/W	baud rate	1200...115200	RS232 Interface baud rate. Default: 9600
echo	R/W	echo	0 or 1	RS232 Interface echo control. 0 - disabled, 1 - enabled
verbose	R/W	verbose	0 or 1	Exit Code format. 0 - numeric, 1 - verbose
aserver port	R/W	aserver port	integer	aserver TCP port. Default: 10102
aserver prompt	R/W	aserver prompt	0 or 1	aserver prompt control
deg	R/W	deg C/F	C/c or F/f	Temperature scale Celsius or Fahrenheit
melody	R?W	melody	string	Power Up melody. The value is printed as melody name, to change the melody its number should be typed. set melody will list supported melodies and their numbers.
filter visi	R/W	filter	visi 0 or visi 1 or visi -	Indoor Units visibility regarding props command. [-] - props visibility applies only to LCD, [1] - props visibility applies to LCD and status/control commands, [0] - props visibility logic is inverted and it applies to LCD and status/control commands

HVAC Lines	RO	HVAC Lines	0..8	Allowed number of HVAC lines. Can be changed with encoded activation string.
------------	----	------------	------	--

* - Bold values are defaults.

EXAMPLE

Disable echo

```
>set echo 0
```

```
OK
```

Change aserver TCP port

```
>set aserver port 12345
```

```
OK
```

Load defaults

```
>set defaults
```

```
OK
```

Apply props visibility to status/control commands

```
>set filter visi 1
```

```
OK, Boot Required!
```

Set RS232 Interface to 19200, 8 data bits, even parity, 1 stop bit

```
>set baud 19200 8E1
```

```
OK
```

Set temperature scale to Fahrenheit

```
>set deg f
```

```
OK
```

Set PowerUp melody to 3

```
>set melody 3
```

```
OK
```

line

SYNOPSIS

```
line
```

```
line <PROPERTY> <Ln> <VAL>
```

DESCRIPTION

Query or change [HVAC Line\(s\)](#) status and configuration. In format without parameters **line** command will provide information about current Line statuses. Second format is used to change write enabled properties.

<PROPERTY>	Mode	Value	Description	Notes
master	R/W	0 or 1	CoolMasterNet acts as a Master device	DK, LG, SA, TO, PN only
simul	R/W	integer	Simulate given number of Indoor Units. To disable simulation use "0". Simulation is persistent (not disabled after power reset) By default the simulation model is: with failures, no ventilation units, no input/output units. To enable/disable special conditions use the following flags: +/-flr, +/-vam, +/-io (see example)	Input/Output units for ME only Ventilation units for DK, ME, LG only
myid	R/W	string	CoolMasterNet Own address on given HVAC Line. For ModBus RTU Line myID is a "Slave Device Address"	
baud	R/W		Configure UART parameters for given Line. Value format is: <BAUD> <8 9><N E O><1 2>	Where applicable

			For example: 9600 8N1	
Tx	RO	integer counter	Transmitted messages	Printed as Last/Total Last means since previous print
Rx	RO		Received messages	
TO	RO		Timeout errors	
CS	RO		Checksum errors	
Col	RO		Collision errors	
NAK	RO		NAK errors	
haux	R/W	heat or haux	Heat mode treated as Haux mode. This is only for situation when HomeAutomation controller doesn't have Haux support, but need to set Haux mode on ThermoPad(s) connected to CH line.	For CoolHub (CH) line only
type	R/W	string	Define line type by acronym . Number of HVAC lines cannot exceed the value of HVAC lines in set command. HomeAutomation/BMS lines don't count as HVAC Lines. To free a line use Unused instead of acronym.	See the full list of HVAC and HomeAutomation/BMS lines supported

scan	R/W	0 or 1	Implicitly detect Indoor Units	ME, HT, SA, TO, PN only
DCOUT	R/W	- or +	Control DC output on L1,L2	DK,ME only
slink	R/W	O/o or N/n	Configure Mitsubishi Heavy SuperLink mode: O - old, N - new	MH only
			Configure Samsung model type: O - DVM, N - DVM-S	SM only
[A B] or [B A]	RO		Current polarity	Line L7 only

EXAMPLE

```
>line
L1: SA U00/G02 myID:E5
Tx:732/732 Rx:47227/47227 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L2: DK Master U00/G07 myID:0B
Tx:4579/4579 Rx:50633/50633 TO:3/3 CS:0/0 Col:10/10 NAK:0/0
L3: Unused
Tx:0/0 Rx:0/0 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L4: Unused
Tx:0/0 Rx:0/0 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L5: Unused
Tx:0/0 Rx:0/0 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L6: Unused
Tx:0/0 Rx:0/0 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L7: MH SLink:N U00/G02 myID:C900 [A|B]
Tx:20072/20072 Rx:26989/26989 TO:25/25 CS:0/0 Col:1/1 NAK:0/0
OK
```

Become Slave on Line L4

```
>line master L4 0
OK, Boot Required!
```

Set Line L3 baud rate to 19200, 8 data bits, even parity, 1 stop bit

```
>line baud L3 19200 8E1
```

```
OK, Boot Required!
```

Simulate 5 Units on line L2 without failures, no ventilation units and with input/output units

```
>line simul L2 5 -flr-vam+io
```

```
OK, Boot Required!
```

Heat mode will be treated as haux for ThermoPads connected to CH line

```
>line haux L3 heat
```

```
OK, Boot Required!
```

Make Line L2 Unused

```
>line type L2 Unused
```

```
OK, Boot Required!
```

Make Line L2 to work with TO HVAC type

```
>line type L2 TO
```

```
OK, Boot Required!
```

HDL Bus Pro on Line L3

```
>line type L3 HDL
```

```
OK, Boot Required!
```

ifconfig

SYNOPSIS

```
ifconfig
ifconfig <PROPERTY> <VALUE>
ifconfig enable|disable
```

DESCRIPTION

Query or configure Ethernet network settings. Without parameters, **ifconfig** command will list current configuration. To change configuration use format with **<PROPERTY>** and **<VALUE>**. Parameter **IP** can be set to **DHCP** (DHCP client) or fixed IP number. In case of DHCP - Netmask and Gateway values are provided by DHCP server. By default CoolMasterNet is configured for DHCP client operation. CoolMasterNet Ethernet module can be enabled or disabled with corresponding command.

<PROPERTY>	Mode	Value	Description	Notes
MAC	RO	string	MAC (Media Access Control) address of CoolMasterNet	
Link	RO	Up or Down	Indicate whether ethernet link is active	
IP	R/W	string	Set fixed (static) IP address or set it to DHCP	
Netmask	R/W	string	Set Netmask address in case IP is static	
Gateway	R/W	string	Set Gateway address in case IP is static	
DNS1	R/W	string	Set preferred DNS address	
DNS2	R/W	string	Set alternate DNS address	

EXAMPLE

Query

```
>ifconfig
MAC      : 28:3B:96:00:02:0F
Link     : Up
IP       : 192.168.16.108 (DHCP)
Netmask: 255.255.255.0
Gateway: 192.168.16.254
DNS1     : 8.8.8.8
DNS2     : 8.8.4.4
OK
Configure fixed IP, Gateway and Netmask
>ifconfig IP 192.168.1.102
OK, Boot Required!
>ifconfig Gateway 192.168.1.0
OK, Boot Required!
>ifconfig Netmask 255.255.0.0
OK, Boot Required!
Configure DHCP client operation
>ifconfig IP DHCP
OK, Boot Required!
Disable Ethernet
>ifconfig disable
OK, Boot Required!
Change DNS preferred address
>ifconfig DN1 208.67.222.222
OK, Boot Required!
```

boot

SYNOPSIS

```
boot
boot [N]
```

DESCRIPTION

- <N> omitted - Enter Boot Mode
- <N> = 2 - Reset CoolMasterNet

sddp

SYNOPSIS

```
sddp
sddp <enable|disable|identify|offline|alive>
```

DESCRIPTION

Configure Control4® Simple Device Discovery Protocol (SDDP) module. CoolMasterNet is compliant with Control4® SDDP v1.0 specification and can act as SDDP enabled device.

- Without parameters, if SDDP module was enabled and Ethernet cable connected, **sddp** command will list supported protocol version and packet counters.
- **sddp enable** - persistently enables SDDP module (effective after reset). Default state.
- **sddp disable** - persistently disables SDDP module (effective after reset)

- `sddp identify` - sends IDENTIFY message to Control4® Composer tool to add CoolMasterNet to the current project
- `sddp offline` - signals that CoolMasterNet is going offline
- `sddp alive` - signals that CoolMasterNet is online

EXAMPLE

Enable SDDP module

```
>sddp enable
```

```
OK, Boot Required!
```

Send IDENTIFY message

```
>sddp identify
```

```
OK
```

knx

SYNOPSIS

```
knx
knx addr <area/line/device>
knx ram <R>
knx funcs
knx group
knx group <GA>[ <func> <direction> <UID>]
knx group dellall
knx group -<G>
```

DESCRIPTION

Query or change KNX status and configuration. In format without parameters **knx** command will provide information about current connection status and number of used groups.

- **knx addr <area/line/device>** - Set KNX physical address in the form of area/line/device
- **knx ram <R>** - Create group Data Base for R groups. The operation will take effect after reboot. Use this operation only if default group Data Base is too small. The current Data Base usage can be seen in **knx** command.
- **knx funcs** - Print all available group functions.
- **knx group** - List existing KNX groups (linkage status)
- **knx group <GA>** - List existing KNX groups (linkage status) for the given group address
- **knx group <GA> <func> <direction> <UID>** - Create new KNX group, i.e. link KNX group address <GA> with CoolMasterNet function and UID. <GA> can be in the form of Main/Mid/Sub or Main/Sub, direction: < - CoolMasterNet input, > - CoolMasterNet output.
- **knx group dellall** - Delete all KNX groups
- **knx group -<G>** - Delete KNX group number <G>. Group numbers displayed in the list of existing groups.

SUPPORTED FUNCTIONS

Name used in command	Full name	Values	Data type	Can be sent to CoolMasterNet	Can be sent from CoolMasterNet
onoff	On/Off	0 - off, 1 - on	1.001	✓	✓
ST	Set temperature	float value according to data type	9.001	✓	✓

RT	Room Temperature	float value according to data type	9.001	✓	✓
Mode	Mode value	0 - cool, 1 - heat, 2 - auto, 3 - dry, 5 - fan	5.010	✓	✓
M	Mode	0 - cool, 1 - heat	1.001	✓	✓
Fstep	Fan speed step	0 - previous fan speed, 1 - next fan speed (according to fspeed_properties*)	1.001	✓	
F8	Fan speed count	value is a sequential fan speed regarding allowed fan speeds in fspeed_properties*	5.010	✓	✓
F%	Fan speed scale %	the percent value is converted to fan speed count (previous function) and then to actual fan speed, the steps are inverted when fan speed is sent from CoolMasterNet	5.001	✓	✓

Notes:

* - If properties record doesn't exist default fan speeds are used: low, medium, high, auto

EXAMPLE

Print KNX status

```
>knx
```

```
KNX Line : Not Detected
```

```
KNX RAM : 7/128
```

```
OK
```

Create KNX group: link 10/0/1 with L1.100 as CoolMasterNet Mode input

```
>knx group 10/0/1 M < L1.100
```

```
OK
```

Create KNX group: link 10/0/1 with L1.100 as CoolMasterNet Room Temperature output

```
>knx group 10/0/1 RT > L1.100
```

```
OK
```

List KNX group for group address 10/0/1

```
>knx group 10/0/1
```

```
G000:10/0/1 [ On/Off ] < L1.100
```

```
G001:10/0/1 [ Mode ] < L1.100
```

```
G002:10/0/1 [ Room temperature ] > L1.100
```

```
OK
```

Print all available group functions

```
>knx group 10/0/1
```

```
onoff -> On/Off DT:{1.001} [<|>]
```

```
ST -> Set temperature DT:{9.001} [<|>]
```

```
RT -> Room temperature DT:{9.001} [<|>]
```

```
M -> Mode DT:{1.001} [<|>]
```

```
Fstep -> Fan speed step DT:{1.001} [<| ]
```

```
F8 -> Fan speed count DT:{5.010} [<|>]
```

```
F% -> Fan speed scale % DT:{5.001} [<|>]
```

```
OK
```

Delete group number 2

```
>knx group -2
OK
```

props

SYNOPSIS

```
props
props <UID_STRICT> <PROPERTY> <VAL>
props delall
```

DESCRIPTION

Query or change CoolMasterNet internal database of Indoor Unit properties. Changes made in database have no impact on physical capabilities of related indoor units.

In format without parameters **props** command will list all stored properties in table view.

<PROPERTY>	Mode	Value	Description	Notes
name	R/W	string	Alternate name of the Indoor Unit to be shown on CoolMasterNet's LCD screen. By default, this property is not defined and UID is shown instead.	
visible	R/W	0 or 1	Defines Indoor Unit visibility on LCD screen. 0 - invisible, 1 - visible. Also depends on filter setting.	Effective after reboot
fspeed	R/W	<+ ->v, l, m, h, t, a	Defines Indoor Unit fan speeds available via LCD touch screen control and commands to/from KNX bus. + allow, - forbid, v - very low/quiet, l - low, m - medium, h - high, t - top, a - auto.	a number of properties can be combined in one command (see examples below)
mode	R/W	<+ ->c, d, f, h, hx, hh, a	Defines Indoor Unit operation modes available via control commands to/from KNX bus. c - cool, d - dry, f - fan, h - heat, hx - haux, hh - heat & haux, a - auto	

Notes:

Bold values represent defaults.

Indoor Unit properties record is created only upon first change in database made for this unit.

Command **props delall** will totally erase database, returning all properties to their default values.

EXAMPLE

Add name property to Indoor Unit 204 on line L6

```
>props L6.204 name Kitchen
OK
```

Make Indoor Unit 102 on line L1 invisible on LCD

```
>props L1.102 visible 0
OK, Boot Required!
```

Forbid medium and auto fan speeds to Indoor Unit 107 on line L2

```
>props L1.102 fspeed -m-a
```

```
OK
```

Allow only cool, fan and haux modes to Indoor Unit 101 on line L1

```
>props L1.101 mode +c+f+hx-h-d-hh-a
```

```
OK
```

List all stored properties

```
>props
```

UID	Name	Visi	Modes	Fspeeds
L6.204	Kitchen	1	c d f h a	l m h a
L1.102	-	0	c d f h a	l m h a
L2.107	-	1	c d f h a	l h
L1.101	-	1	c f hx	l m h a

```
OK
```

link

SYNOPSIS

```
link
link delall
link -L
link ram R
link <UID1_STRICT><=|~><UID2_STRICT>
```

DESCRIPTION

Control link operation in CoolMasterNet. Linking ThermoPad on [CoolHub](#) line with Indoor Unit will grant the ThermoPad full control over the Unit.

- In format without parameters `link` will list existing links
- `link delall` - delete all links
- `link -L` - delete link number L (link numbers displayed in the list of existing links)
- `link ram R` - create link Data Base for R groups. The operation will take effect after reboot. Use this operation only if default link Data Base is too small.
- `link <UID1_STRICT><=|~><UID2_STRICT>` - create new link, where UID1 is ThermoPad on [CoolHub](#) line and UID2 is Indoor Unit. The command generate invisible [property](#) for one of the UID's. `<=|~>` defines link type: = regular link, the ThermoPad will become invisible; ~ link with haux mode usage, the Indoor Unit will become invisible. Regular link will allow to control the Indoor Unit through UID2, while haux link through UID1.

EXAMPLE

List existing links

```
>link L3.082=L1.101
```

```
L000: L3.081 <--> L7.096
```

```
L001: L3.083 <--> L1.100
```

```
OK
```

Delete link number 0

```
>link -0
```

```
OK
```

Link ThermoPad 082 on line L3 with Indoor Unit 101 on line L1 (regular link)

```

>link L3.082=L1.101
OK, Boot Required!
Link ThermoPad 080 on line L3 with Indoor Unit 100 on line L1 (haux link)
>link L3.080~L1.100
OK, Boot Required!
Delete all links
>link delall
OK
Create link Data Base for 60 links
>link ram 60
OK, Boot Required!

```

plug**SYNOPSIS**

```
plug <UID_STRICT> <ASCII I/F command>
```

DESCRIPTION

Forward ASCII I/F command to CoolPlug device connected to CH line. CoolPlug device is recognized by CoolMasterNet as Indoor Unit referenced by [UID](#).

EXAMPLE

Send **set** command to CoolPlug device 080 on CoolMasterNet line L3

```

>plug L3.080 set
S/N           : 00E60100
version       : 0.0.2
baud rate     : 9600
echo          : 1
verbose       : 1
deg C/F       : C
HVAC lines    : 1
OK
OK

```

Query lines status of CoolPlug device 080 on CoolMasterNet line L3

```

>plug L3.080 line
L1: P1P2 A:Master U00/G10 Simul(10) Not Main RC
Tx:1154/1695 Rx:1153/1694 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L2: PB Address:0x50(80) 9600_8N1
Tx:752/1038 Rx:1497/2319 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
OK
OK

```

ad**SYNOPSIS**

```
ad <Ln> <ASCII I/F command>
```

DESCRIPTION

Forward ASCII I/F command to CMNET-GR-GMV5 device connected to GMV5 line.

EXAMPLE

Send **set** command to CMNET-GR-GMV5 on CoolMasterNet line L8

```
>ad L8 set
S/N           : 12345678
version       : 0.0.2
baud rate     : 9600
echo          : 1
verbose       : 1
OK
>OK
```

Query current lines status of CMNET-GR-GMV5 on CoolMasterNet line L8

```
>ad L8 line
L1: CAN Speed:50000 myid:728
Tx:0/0 Rx:0/0 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
L2: CAN Speed:50000 myid:728
Tx:0/0 Rx:0/0 TO:0/0 CS:0/0 Col:0/0 NAK:0/0
OK
>OK
```

hdl**SYNOPSIS**

```
hdl
hdl delall
hdl - <UID_STRICT>
hdl + <UID_STRICT> <channel> <AC_No> <enable>
<m0m1m2m3m4f0f1f2f3>
hdl eth
hdl eth <enable|disable>
hdl eth myid <ID>
```

DESCRIPTION

Query or change HDL status and configuration. In format without parameters **hdl** command will list existing AC (Air Condition) configurations in similar way it is displayed in HDL Buspro Setup tool.

- **hdl delall** - delete all AC configurations
- **hdl - <UID_STRICT>** - delete AC configuration for specific Indoor Unit
- **hdl + <UID_STRICT> <channel> <AC_No> <enable> <m0m1m2m3m4f0f1f2f3>** - create AC configuration for Indoor Unit. All parameters are taken from AC configurations table in HDL Buspro Setup tool: channel - line number in AC configurations table, AC_No - integer number to bind to Indoor Unit, enable - 0 (invalid) or 1 (valid), modes - m0=cool m1=heat m2=fan m3=auto m4=dry, fan speeds - f0=auto f1=high f2=medium f3=low; +=allowed -=not allowed (see example).
- **hdl eth** - print HDL ethernet status and packet counters
- **hdl eth <enable|disable>** - enable/disable HDL over ethernet
- **hdl eth myid <ID>** - change Subnet and Device ID: the ID is entered in hexadecimal format, MS byte is Subnet ID, LS byte is Device ID (see example)

Notes:

Subnet ID and Device ID of HDL RS485 line can be changed with [line myid](#) command.

EXAMPLE

List existing AC configurations

```
>hdl
```

Ch	AC	En	Remark	CA	CHFAD	AHML
1	1	1	L1.100	L1.100	++---	-+++
2	2	1	L1.101	L1.101	++++-	++++

```
OK
```

Delete AC configuration for Indoor Unit L1.101

```
>hdl - L1.101
```

```
OK
```

Create AC configuration for Indoor Unit L2.301: channel=2, AC number=2, valid, modes=cool heat, fan speeds=high medium

```
>hdl + L2.301 2 2 1 ++-----++
```

```
OK
```

HDL ethernet status

```
>hdl eth
```

```
status      : enabled
ID          : 0x01 0x63
send cntr   : 0
recv cntr   : 0
crc cntr    : 0
```

```
OK
```

Enable HDL over ethernet

```
>hdl eth enable
```

```
OK, Boot Required!
```

Change HDL ID of CoolMasterNet: Subnet ID=0x01=1, Device ID=0x63=99

```
>hdl eth myid 0163
```

```
OK, Boot Required!
```

simul**SYNOPSIS**

```
simul [Ln] <CNT>
```

DESCRIPTION

Simulate <CNT> Indoor Units on HVAC Line <Ln>. If <Ln> is omitted the first not "Unused" HVAC Line will be taken. Simulation is not persistent and CoolMasterNet reset will terminate it.

EXAMPLE

Simulate 5 Indoor Units on HVAC Line L2

```
>simul L2 5
```

```
OK
```

gpio**SYNOPSIS**

```
gpio
gpio func <A|B|C|D> <GPIO_FUNCTION>
gpio norm <A|B|C|D> <c|C|o|O>
```

DESCRIPTION

Query or configure [GPIO](#) functionality. GPIO configurations are persistent (over power reset) and take effect only after reboot.

- Without parameters `gpio` command provides information about current GPIO configuration in the below format:

```
>gpio
A: ALL OFF (HI), N.O.
B: ALL ON (LO), N.C.
C: Unused (HI)
D: Unused (HI)
OK
```

Field	Value	Description
GPIO name	A,B,C,D	
GPIO function	Unused	GPIO has no functionality and stays in HiZ input state
	ALL OFF Input	Turn all Indoor Units OFF in transition from Normal to Active state
	ALL ON Input	Turn all Indoor Units ON in transition from Normal to Active state
	OOS Output	On/Off Status. GPIO is in Normal state if all Indoor Units are OFF. GPIO is in Active state if at least one Indoor Units is ON
	ALL INH Input	Turn all Indoor Units OFF in transition from Normal to Active state. Hold Indoor Units OFF while GPIO is in Active State. Upon transition from Active to Normal state turn ON Indoor Units that were ON before
	FLRS Output	Failure Status. GPIO is in Normal state if all Indoor Units have no failure. GPIO is in Active state if at least one Indoor Units has a failure
Current GPIO Signal Level	(HI)	Signal Level on GPIO is HI
	(LO)	Signal Level on GPIO is LO
Signal Level in Normal State	N.O.	Normal state of GPIO is "Normally Open" (HI)
	N.C.	Normal state of GPIO is "Normally Closed" (LO)

- `gpio func <A|B|C|D> <GPIO_FUNCTION>`
Configure GPIO function. Supported GPIO functions are listed in table above.
- `gpio norm <A|B|C|D> <c|C|o|O>`
Configure Normal state of GPIO.

EXAMPLE

```
Disable GPIO A functionality
>gpio func A Unused
OK, Boot Required!
```

```
Set GPIO C function to "ALL OFF"
>gpio func C ALL OFF
OK, Boot Required!
```

```
Set Normal state of GPIO A to N.C.
>gpio norm A C
OK
```

info**SYNOPSIS**`info`**DESCRIPTION**

Query CollMasterNet dip switches position and DC output on lines L1 and L2.

```
>info
DIP P: | X | OFF | X | X |
DIP Q: | ON | X | ON | X |
DIP R: | X | X | X | X |
DIP S: | X | ON | ON | ON |
L1 DC- OFF 0V
L2 DC+ ON 16V
OK
```

Parameter		Description	
DIP switch	ON	DIP switch is ON	
	OFF	DIP switch is OFF	
	X	DIP switch can't be read	
Line DC	+	DCOUT enable command was given to CoolMasterNet	
	-	DCOUT disable or no command at all was given to CoolMasterNet	
	0v	No voltage detected on the line	
	16v	16 volt detected on the line (own or external)	
	ON	CoolMasterNet enabled DC output on the line	On reboot, CoolMasterNet will enable DC output only if DCOUT enable command was given and DIP switch S is in correct position, otherwise it will disable DC output
	OFF	CoolMasterNet disabled DC output on the line	

modbus**SYNOPSIS**

```
modbus [<SETTING> <VALUE> ]
modbus cg4
```

DESCRIPTION

Query or change CoolMasterNet ModBus configurations. Without parameters **modbus** command will list current ModBus configurations.

<SETTING>	Mode	Printed as	Value	Description
IP	R/W	ModBus IP	enable or disable	Enable/Disable ModBus IP server
server port	R/W	server port	integer	Change Modbus IP server port
ignore	R/W	CG4 ignore*	r	The setting is toggable, first command will enable the setting, second will disable (see example)
cg4	RO			List CoolGate 4 ModBus addresses of existing (visible with ls command) Indoor Units

Notes:

* - This setting is applicable only for [CoolGate 4](#). When the setting is enabled it will allow to read/write registers of several indoors by one request. Pay attention that there are reserved registers for every indoor, that will return an error when read/write requested without this setting. If the read request started from one of the readable registers (not reserved) the values of reserved registers will be 0xFFFF in the response. If the read request started from reserved register the response will be illegal data address. In a similar way it works with the write request. If the write request started from one of the writable registers (not reserved) the values that were intended for reserved registers will be ignored. If the write request started from one of the reserved registers the response will be illegal data address.

EXAMPLE

List current ModBus configuration

```
>modbus
```

```
ModBus IP      : disabled
```

```
server port    : 502
```

```
CG4 ignore     : none
```

```
OK
```

Enable ignore setting

```
>modbus ignore r
```

```
OK
```

List current ModBus configuration

```
>modbus
```

```
ModBus IP      : disabled
```

```
server port    : 502
```

```
CG4 ignore     : regs
```

```
OK
```

Disable ignore setting

```
>modbus ignore r
```

```
OK
```

Enable ModBus IP

```
>modbus IP enable
```

```
OK, Boot Required!
```

Change ModBus IP server port

```
>modbus server port 500
```

```
OK, Boot Required!
```

List CoolGate 4 ModBus addresses of existing Indoor Units

```
>modbus cg4
```

```
L1.100 --> Hex: 0x1001, Dec: 4097
```

```
L1.101 --> Hex: 0x1011, Dec: 4113
```

```
OK
```

6.2.2 HVAC Status and Control Commands

[on](#)

[allon](#)

[off](#)

[alloff](#)

[cool](#)

[heat](#)

[fan](#)

[dry](#)

[auto](#)
[temp](#)
[fspeed](#)
[vam](#)
[filt](#)
[swing](#)
[stat](#)
[ls](#)
[ls2](#)
[query](#)
[feed](#)
[main](#)
[wh](#)
[vam](#)
[lock](#)
[inhibit](#)
[group](#)
[va](#)

on

SYNOPSIS

on [[UID](#)]

DESCRIPTION

Turn on Indoor Unit(s).

EXAMPLE

Turn on Indoor Unit 102 on line L1

```
>on L1.102
```

```
OK
```

Turn on all Indoor Units on Line L2

```
>on L2*
```

```
OK
```

Turn on all Indoor Units

```
>on
```

```
OK
```

allon

SYNOPSIS

allon

DESCRIPTION

Turn on all Indoor Units.

off**SYNOPSIS**

```
off [UID]
```

DESCRIPTION

Turn off Indoor Unit(s).

EXAMPLE

Turn off Indoor Unit 102 on line L1

```
>off L1.102
```

```
OK
```

Turn off all Indoor Units on line L2

```
>off L2*
```

```
OK
```

Turn off all Indoor Units

```
>off
```

```
OK
```

alloff**SYNOPSIS**

```
alloff
```

DESCRIPTION

Turn off all Indoor Units.

cool**SYNOPSIS**

```
cool [UID]
```

DESCRIPTION

Set Indoor Unit(s) operation mode to cool.

EXAMPLE

Set Indoor Unit 102 on line L1 to cool mode

```
>cool L1.102
```

```
OK
```

Set all Indoor Units on line L2 to cool mode

```
>cool L2*
```

```
OK
```

Set all Indoor Units to cool mode

```
>cool
```

```
OK
```

heat**SYNOPSIS**

```
heat [UID]
```

DESCRIPTION

Set Indoor Unit(s) operation mode to heat.

EXAMPLE

Set Indoor Unit 102 on line L1 to heat mode

```
>heat L1.102
```

```
OK
```

Set all Indoor Units on line L2 to heat mode

```
>heat L2*
```

```
OK
```

Set all Indoor Units to heat mode

```
>heat
```

```
OK
```

fan**SYNOPSIS**

```
fan [UID]
```

DESCRIPTION

Set Indoor Unit(s) operation mode to fan.

EXAMPLE

Set Indoor Unit 102 on line L1 to fan mode

```
>fan L1.102
```

```
OK
```

Set all Indoor Units on line L2 to fan mode

```
>fan L2*
```

```
OK
```

Set all Indoor Units to fan mode

```
>fan
```

```
OK
```

dry**SYNOPSIS**

```
dry [UID]
```

DESCRIPTION

Set Indoor Unit(s) operation mode to dry.

EXAMPLE

Set Indoor Unit 102 on line L1 to dry mode

```
>dry L1.102
```

```

OK
Set all Indoor Units on line L2 to dry mode
>dry L2*
OK
Set all Indoor Units to dry mode
>dry
OK

```

auto

SYNOPSIS

```
auto [UID]
```

DESCRIPTION

Set Indoor Unit(s) operation mode to auto.

EXAMPLE

```

Set Indoor Unit 102 on line L1 to auto mode
>auto L1.102
OK
Set all Indoor Units on line L2 to auto mode
>auto L2*
OK
Set all Indoor Units to auto mode
>auto
OK

```

temp

SYNOPSIS

```
temp [UID] [ $\pm$ ]<TEMP>
temp [UID] <TEMP.d>
```

DESCRIPTION

Change Indoor Unit(s) Set Temperature.

- In form **temp [UID] [\pm]<TEMP>**
<TEMP> parameter must be decimal natural number. Command can work in relative or absolute manner. If plus '+' or minus '-' sign precedes **<TEMP>** parameter it's value will be added to or substituted from current Set Temperature value. Otherwise Set Temperature will be set to the given **<TEMP>** value.
- In form **temp [UID] <TEMP.d>**
Set Temperature parameter **<TEMP.d>** is a fractal number with 0.1 precision. (In this case preceding +/- are not allowed). If HVAC System does not support 0.1 precision for the Set Temperature (see table below), the final value will be nearest supported value.

AC Type	Set Temperature Precision
DK	0.1°C
ME	0.1°C

SM	0.1°C
FJ	0.3°C
SA	0.5°C
TO	0.5°C
PN	0.5°C
MH	0.5°C
LG	0.5°C
HT	1°C
GR	1°C
MD,CG,KT,TR	1°C
TI	1°C
MT	1°C
BSM	1°C

The **deg** setting (see [set](#) command) defines which temperature scale Celsius or Fahrenheit is used for **<TEMP>** and **<TEMP.d>** parameters value.

EXAMPLE

Set Indoor Unit 102 on line L1 Set Temperature to 23°

```
>temp L1.102 23
```

```
OK
```

Decrease all Indoor Units on line L2 Set Temperature by 2°

```
>temp L2* -2
```

```
OK
```

Set all Indoor Units on line L2 Set Temperature to 24.5°

```
>temp L2* 24.5
```

```
OK
```

Set all Indoor Units Set Temperature to 22°

```
>temp 22
```

```
OK
```

```
-----OLD_TEXT-----
```

SYNOPSIS

```
temp [UID] [±]<TEMP>
```

```
temp [UID] <TEMP.d>
```

DESCRIPTION

Change Indoor Unit(s) Set Temperature.

- In form **temp [UID] [±]<TEMP>**

<TEMP> parameter must be decimal natural number. Command can work in relative or absolute manner. If plus '+' or minus '-' sign precedes **<TEMP>** parameter it's value will be added to or substituted from current Set Temperature value. Otherwise Set Temperature will be set to the given **<TEMP>** value.

- In form **temp [UID] <TEMP.d>**

Set Temperature parameter **<TEMP.d>** is a fractal number with 0.1 precision. (In this case preceding +/- are not allowed). If HVAC System does not support 0.1 precision for the Set Temperature (see table below), the final value will be nearest supported value.

AC Type	Set Temperature Precision
DK	0.1°C
ME	0.1°C
SM	0.1°C
FJ	0.3°C
SA	0.5°C
TO	0.5°C
PN	0.5°C
MH	0.5°C
LG	0.5°C
HT	1°C
GR	1°C
MD,CG,KT,TR	1°C
TI	1°C
MT	1°C

The **deg** setting (see [set](#) command) defines which temperature scale Celsius or Fahrenheit is used for **<TEMP>** and **<TEMP.d>** parameters value.

EXAMPLE

Set Indoor Unit 102 on line L1 Set Temperature to 23°

```
>temp L1.102 23
```

```
OK
```

Decrease all Indoor Units on line L2 Set Temperature by 2°

```
>temp L2* -2
```

```
OK
```

Set all Indoor Units on line L2 Set Temperature to 24.5°

```
>temp L2* 24.5
```

```
OK
```

Set all Indoor Units Set Temperature to 22°

```
>temp 22
```

```
OK
```

feed

SYNOPSIS

```
feed [UID] [±]<TEMP>
```

```
feed [UID] <TEMP.d>
```

DESCRIPTION

Provides Ambient Temperature suggestion for given Indoor Unit(s). If **<TEMP>** is zero CoolMasterNet will not suggest Ambient Temperature. Suggested Ambient Temperature is not persistent and is lost (set to zero) after power reset of CoolMasterNet.

- In form **feed [UID] [±]<TEMP>**

<TEMP> parameter must be decimal natural number. Command can work in relative or absolute manner. If plus '+' or minus '-' sign precedes <TEMP> parameter it's value will be added to or substituted from the current Ambient Temperature suggested value. Otherwise it will be set to the given <TEMP> value.

- In form **feed [UID] <TEMP.d>**

Parameter <TEMP.d> is a fractal number with 0.1 precision. (In this case preceding +/- are not allowed).

It is not guaranteed that the Ambient Temperature reported by Indoor Unit will be equal to the suggested Ambient Temperature provided with **feed** command. The **feed** command is supported for the following AC types:

AC Type	Firmware Version
ME	
PBM	
SI	0.4.7
KNX	
EL	
GRNS	

EXAMPLE

Suggest Room Temperature of 23.5° for Indoor Unit L1.102

```
>feed L1.102 23.5
```

```
OK
```

Decrease suggested Room Temperature for all Indoor Units on line L2 by 2°

```
>feed L2* -2
```

```
OK
```

fspeed

SYNOPSIS

```
fspeed [UID] <v,V|l,L|m,M|h,H|t,T|a,A>
```

DESCRIPTION

Set Indoor Unit(s) Fan Speed to:

- v, V - very low or quiet
- l, L - low
- m, M - medium
- h, H - high
- t, T - top or very high
- a, A - auto

Not all Indoor Units support Fan Speed options listed above. Specific Fan Speeds support depend on specific Indoor Unit capabilities. If requested Fan Speed is not supported by Indoor Unit(s) **fspeed** command will have no effect.

EXAMPLE

Set Indoor Unit 102 on line L1 Fan Speed to low

```
>fspeed L1.102 l
```

```
OK
```

Set all Indoor Units on Line L2 Fan Speed to high

```
>fspeed L2* h
```

```
OK
```


Set all Indoor Units Fan Speed to medium

```
>fspeed m
```

```
OK
```

swing

SYNOPSIS

```
swing [UID] <h|v|a|3|4|6|x>
```

DESCRIPTION

Set Indoor Unit(s) louver position to:

- h - horizontal
- v - vertical
- a - auto (swing)
- 3 - 30°
- 4 - 45°
- 6 - 60°

Not all Indoor Units support louver position options listed about or have louver position control at all. Louver control is capability of the specific Indoor Unit type. If requested louver position is not supported by Indoor Unit(s), **swing** command will have no effect or will return an error.

EXAMPLE

Set Indoor Unit 102 on line L1 louver to horizontal position

```
>swing L1.102 h
```

```
OK
```

Set all Indoor Units louver to 30° position

```
>swing 3
```

```
OK
```

filt

SYNOPSIS

```
filt [UID]
```

DESCRIPTION

Reset Filter Sign.

EXAMPLE

Reset Filter Sign on Indoor Unit 102 On line L1

```
>filt L1.102
```

```
OK
```

Reset Filter Sign on all Indoor Units on Line L2

```
>filt L2*
```

```
OK
```

Reset Filter Sign on all Indoor Units

```
>filt
```

```
OK
```

stat**SYNOPSIS**

```
stat [UID]
stat2 [UID]
stat3 [UID]
stat4 [UID]
```

DESCRIPTION

Get Indoor Unit(s) status list.

These commands are deprecated and are not recommended for use in CoolMasterNet. They are implemented for backward compatibility only. Detailed description of these commands can be found in the PRM of previous CoolMaster versions.

ls**SYNOPSIS**

```
ls [UID]
ls+
```

DESCRIPTION

Get Indoor Unit(s) status list.

In case UID is omitted, **ls** command will list all visible Indoor Units connected to CoolMasterNet, while **ls+** command will list all Indoor Units including the invisible (see [props](#) command) ones.

Indoor Unit status line has strict format, so that every status field is printed at fixed position.

- Indoor Unit status line with Celsius temperature scale

```
0123456789012345678901234567890123456
L2.102 OFF 20C 27C High Cool OK - 0
```

- Indoor Unit status line with Fahrenheit temperature scale

```
012345678901234567890123456789012345678
L2.102 OFF 120F 127F High Cool OK - 0
```

Field	Position in string		Values
	Celsius	Fahrenheit	
UID	0-5		LN.XYY
On/Off	7-9		ON,OFF
Set Temperature	11-12	11-13	nnC or nnnF
Room Temperature	15-16	16-18	nnC or nnnF
Fan Speed	19-22	21-24	VLow, Low, Med, High, Top, Auto, ...
Operation Mode	24-27	26-29	Cool, Heat, Fan, Dry, Auto, ...
Indoor Failure Code	29-32	31-34	OK - no failure, else Indoor Failure Code
Filter Sign	34	36	- or # (Filter Sign)
Demand	36	38	0 or 1

EXAMPLE

```

>ls L2
L2.101 ON 25C 27C Low Cool OK - 1
L2.102 OFF 20C 27C High Cool OK - 0
OK
>ls L2.101
L2.101 ON 25C 27C Low Cool OK - 1
OK
>ls
L1.101 ON 25C 24C Low Cool OK - 1
L1.102 ON 22C 23C Med Cool OK - 0
L2.101 ON 25C 27C Low Cool OK - 1
L2.102 OFF 20C 27C High Cool OK - 0
OK

```

ls2**SYNOPSIS**

```
ls2 [UID]
```

DESCRIPTION

Same as ls, but with decimal precision in temperatures.

Get Indoor Unit(s) status list. If UID is omitted all Indoor Units connected to CoolMasterNet will be listed.

Indoor Unit status line has strict format, so that every status field is printed in fixed position.

- Indoor Unit status line with Celsius temperature scale

```
01234567890123456789012345678901234567890
```

```
L1.102 ON 16.9C 27.0C High Cool OK - 0
```

- Indoor Unit status line with Fahrenheit temperature scale

```
0123456789012345678901234567890123456789012
```

```
L1.102 ON 062.4F 080.6F High Cool OK - 0
```

Field	Position in string		Values
	Celsius	Fahrenheit	
UID	0-5		LN.XYY
On/Off	7-9		ON,OFF
Set Temperature	11-14	11-15	nn.nC or nnn.nF
Room Temperature	17-20	18-22	nn.nC or nnn.nF
Fan Speed	23-26	25-28	VLow, Low, Med, High, Top, Auto
Operation Mode	28-31	30-33	Cool, Heat, Fan, Dry, Auto
Indoor Failure Code	33-36	35-38	OK - no failure, else Indoor Failure Code
Filter Sign	38	40	- or # (Filter Sign)
Demand	40	42	0 or 1

EXAMPLE

```

>ls L2
L2.101 ON 25.7C 27.2C Low Cool OK - 1
L2.102 OFF 20.0C 27.3C High Cool OK - 0
OK

```

```
>ls L2.101
L2.101 ON 25.7C 27.2C Low Cool OK - 1
OK
>ls
L1.101 ON 25.4C 24.1C Low Cool OK - 1
L1.102 ON 22.1C 23.4C Med Cool OK - 0
L2.101 ON 25.7C 27.2C Low Cool OK - 1
L2.102 OFF 20.0C 27.3C High Cool OK - 0
OK
```

query

SYNOPSIS

```
query <UID_STRICT> <o|m|f|t|h|e|a|s>
```

DESCRIPTION

Query one of the operation conditions of given Indoor Unit. <UID_STRICT> parameter must define single Indoor Unit in form Ln.XYY or XYY. Resulting value is printed as alpha-numeric value according to the table below.

Query	Operation Condition	Value
o	On/Off	0 - Off, 1 - On
m	Operation Mode	0 - Cool 1 - Heat 2 - Auto 3 - Dry 4 - Haux 5 - Fan
f	Fan Speed	0 - Low 1 - Medium 2 - High 3 - Auto 4 - Top
t	Set Temperature	Natural
e	Failure Code	0 - No failure, otherwise failure code same as in ls command
a	Ambient Temperature	Natural
h	Set Temperature	0.01° Precision
s	Louver Position	0 - No Louver Control a - auto (swing) h - horizontal 3 - 30° 4 - 45° 6 - 60° v - vertical x - stop (swing)

EXAMPLE

```
>query L1.100 o
1
OK
>query L1.100 m
```

```

0
OK
>query L1.100 t
25
OK
>query L1.100 a
27
OK
>query L1.100 f
2
OK
>query L1.100 e
U4
OK
>query L1.100 e
0
OK
>query L1.100 h
20.50
OK

```

wh**SYNOPSIS**

```

wh <UID_STRICT> <h|e|w|a|t<+|-|temp>|b<+|->>
wh <UID_STRICT>

```

DESCRIPTION

Control Water Heater Unit. When letter is omitted special water heater status is displayed.

Letter	Operation	Compatibility	
		ME	P1P2 (Altherma)
h	Heat Mode	✓	
e	Eco Mode	✓	
w	Hot Mode	✓	
a	Anti-freeze Mode	✓	
t	Tank (+=on, -=off, temp=set point)		✓
b	Booster (+=on, -=off)		✓
"no letter"	Print status		✓

ON/OFF control of the Water Heater Unit is performed with regular [on](#) and [off](#) commands.

EXAMPLE

Set Hot Mode on Water Heater Unit 101 on Line L1

```
>wh L1.101 w
```

```
OK
```

Set Altherma Unit 000 on Line L4 Tank Set Temperature to 40°

```
>wh L4.000 t40
```

```
OK
```

Turn on Tank of Altherma Unit 000 on Line L4

```
>wh L4.000 t+
```

```
OK
```

Turn on Tank Booster of Altherma Unit 000 on Line L4

```
>wh L4.000 b+
```

```
OK
```

Print Tank status of Altherma Unit 000 on Line L4

```
>wh L4.000
```

```
L4.000 ON 40C 35C +
```

```
OK
```

main

SYNOPSIS

```
main [Ln]
```

```
main <UID\_STRICT> <0|1>
```

DESCRIPTION

Change or query Daikin Indoor Units main RC setting. Without parameters **main** command will list main RC setting of all Daikin Indoor Units on all lines. Line number **Ln** can be indicated to list Daikin Indoor Units on specific line.

Main RC setting	Description
+	Indoor Unit is main RC
-	Indoor Unit is not main RC
?	No main RC in the system

Notes:

To set Indoor Unit as main RC the previous main RC have to be unset first.

EXAMPLE

List main RC setting of Indoor Units on line L2

```
>main L2
```

```
L2.200 -
```

```
L2.201 -
```

```
L2.202 -
```

```
L2.203 -
```

```
L2.204 -
```

```
L2.205 -
```

```
L2.206 +
```

```
OK
```

List main RC setting of all Indoor Units

```
>main
```

```
L1.300 -
```

```
L1.301 +
```

```
L1.302 -
```

```
L2.100 ?
```

```
L2.101 ?
```

```
L2.102 ?
```

L2.103 ?

OK

Unset main RC: Indoor Unit 206 on line L2

>main L2.206 0

OK

Set new main RC: Indoor Unit 201 on line L2

>main L2.201 1

OK

vam

SYNOPSIS

vam <UID_STRICT> <a|b|x|n|l|L|h|H|s|t|A|+|->

vam

vam <UID_STRICT>

DESCRIPTION

Control Ventilation Unit.

- vam <UID_STRICT> - get Ventilation Unit status.
- vam - get all Ventilation Units status.

Letter	Operation	Compatibility			
		DK	ME	LG	SM
a	Auto Mode	✓	✓	✓	✓
b	Bypass (Bps) Mode	✓	✓		✓
x	Heat Exchange (HExc) Mode	✓	✓	✓	✓
n	Normal Mode			✓	
S	Sleep Mode				✓
l	Low Fan	✓	✓	✓	✓
L	Low Fan with Fresh-Up	✓			
h	High Fan	✓	✓	✓	✓
H	High Fan with Fresh-Up	✓			
s	Super High Fan			✓	✓
t	Top Fan		✓		
A	Auto Fan		✓	✓	
+	Turn on ventilation unit*				✓
-	Turn off ventilation unit*				✓

ON/OFF control of the Ventilation Unit is performed with regular [on](#) and [off](#) commands.

There are, though, dual units, that consist of Air Condition Unit and Ventilation unit. In this case [on](#) and [off](#) commands will control the Air Condition Unit, while `vam <UID_STRICT> +/vam <UID_STRICT> -` will control the Ventilation Unit.

EXAMPLE

Set Heat Exchange mode on Ventilation Unit 101 on Line L1

>vam L1.101 x

OK

lock**SYNOPSIS**

```
lock <UID_STRICT>
lock [UID] <-|+>[o|m|t|n]
```

DESCRIPTION

Most of the HVAC systems have a prohibit/lock/inhibit functionality to prevent user from changing Indoor Unit status via wired or remote local controller. Same functionality is provided by CoolMasterNet with **lock** command.

- **lock** <UID_STRICT> - Query locks for specific Indoor Unit. <UID_STRICT> defines single Indoor Unit in form Ln.XYY

Lock options	Operation	Compatibility					
		DK	ME, SA, TO, PN, FJ	HT	MD, KT, TR, CG	LG	HA
+	Full Lock: On/Off, Mode, Set Temperature	✓	✓	✓	✓	✓	✓
-	Full Unlock: On/Off, Mode, Set Temperature	✓	✓	✓	✓	✓	✓
+o	Lock On/Off	✓	✓				✓
-o	Unlock On/Off	✓	✓				✓
+m	Lock Mode	✓	✓		✓	✓	✓
-m	Unlock Mode	✓	✓		✓	✓	Use Full Unlock
+t	Lock Set Temperature	✓	✓			✓	✓
-t	Unlock Set Temperature	✓	✓			✓	Use Full Unlock
+n	Lock On	✓					
-n	Unlock On	✓					

Different Lock options can be combined in one command (see examples below)

EXAMPLE

Query locks for Indoor Unit L1.103 (SA/TO/PN)

```
>lock L1.103
```

```
-o -m -t
```

```
OK
```

Query locks for Indoor Unit L2.101 (MD/KT/TR/CG/HT)

```
>lock L2.101
```

```
+
```

```
OK
```

Query locks for Indoor Unit L1.100 (DK)

```
>lock L1.100
```

```
-o -m -t +n
```

```
OK
```

Lock Mode change and Unlock Set Point change

```
>lock L1.102 +m-t
```

```
OK
```

Full Lock

```
>lock L5.002 +
```


OK

inhibit

SYNOPSIS

```
inhibit [UID] <0|1>
```

DESCRIPTION

CoolMasterNet will force Indoor Unit(s) to OFF state, when **inhibit** is set to 1(enabled). Setting **inhibit** back to 0(disabled) restores Indoor Unit(s) ON/OFF state. Indoor Unit will be turned ON if it was ON before the inhibit.

EXAMPLE

Inhibit Indoor Unit 102 on line L1. Unit will be forced OFF.

```
>inhibit L1.102 1
```

OK

Remove Inhibit from Indoor Unit 102 on line L1

```
>inhibit L1.102 0
```

OK

Inhibit all Indoor Units

```
>inhibit 1
```

OK

Remove Inhibit from all Indoor Units

```
>inhibit 0
```

OK

group

SYNOPSIS

```
group
group <UID1_STRICT> <UID2_STRICT>
group delall
group -G
group ram R
```

DESCRIPTION

Control group operation in CoolMasterNet. Grouping of two Indoor Units means that second Indoor Unit will follow ON/OFF, Mode, Fan Speed, Set Temperature and Swing settings of the first Indoor Unit.

- In format without parameters **group** will list existing groups
- **group delall** - delete all groups
- **group -G** - delete group number G (group numbers displayed in the list of existing groups)
- **group <UID1_STRICT> <UID2_STRICT>** - create new group, where UID2 will follow UID1
- **group ram R** - create group Data Base for R groups. The operation will take effect after reboot. Use this operation only if default group Data Base is too small.

EXAMPLE

Group Indoor unit L5.001 with L5.002

```
>group L5.001 L5.002
```

OK

List existing groups

```

>group
G000: L5.001 --> L5.002
G001: L5.001 --> L5.003
OK
Delete group number 0
>group -0
OK
Delete all groups
>group delall
OK
Create group Data Base for 50 groups
>group ram 50
OK, Boot Required!

```

va

SYNOPSIS

```

va
va auto
va delall
va ram R
va - <UID_STRICT | VA>
va + <UID_STRICT> <VA>

```

DESCRIPTION

In order to simplify translation of the [UID](#) into Modbus object address, CoolMasterNet uses VA (Virtual Address), associated with [UID](#). Each [UID](#) can have none, one or a number of associated VA's, but each VA can be associated only with one [UID](#). VA's are plain numbers starting from 001 (decimal). Virtual Address concept is applicable to [CoolGate 5](#) and [ModBus IP](#).

- In format without parameters **va** command will list all VA associations and their ModBus addresses in hexadecimal and decimal format.
- **va auto** - CoolMasterNet will automatically associate VA's with existing (visible with [ls](#) command) [UID](#)'s. This will delete previous associations
- **va delall** - delete all VA associations
- **va ram R** - create VA Data Base for R associations. The operation will take effect after reboot. Use this operation only if default VA Data Base is too small.
- **va - <UID_STRICT | VA>** - delete all VA associations with specific Indoor Unit or delete specific VA association
- **va + <UID_STRICT> <VA>** - add new VA association

EXAMPLE

Auto associate all existing Indoor Units

```

>va auto
OK
Associate VA 007 with Indoor Unit 100 on line L1
>va + L1.100 7
OK
List all VA associations
>va
L1.100 --> 001 [Hex: 0x0011 | Dec: 0017]
      +-> 007 [Hex: 0x0071 | Dec: 0113]

```

```

L1.101 --> 002 [Hex: 0x0021 | Dec: 0033]
L2.101 --> 003 [Hex: 0x0031 | Dec: 0049]
L2.102 --> 004 [Hex: 0x0041 | Dec: 0065]
L2.103 --> 005 [Hex: 0x0051 | Dec: 0081]
L2.104 --> 006 [Hex: 0x0061 | Dec: 0097]
OK
Delete all VA associations of Indoor Unit 100 on line L1
>va - L1.100
OK
Delete VA association number 4
>va - 4
OK
Delete all VA associations
>va delall
OK
Create VA Data Base for 200 associations
>va ram 200
OK, Boot Required!

```

istat**SYNOPSIS**

```

istat [XID]
istat2 [XID]
istata [XID]

```

DESCRIPTION

Print internal Indoor(s) parameters and statuses. All parameters and statuses are AC specific.

Command	Operation	Compatibility				
		DK	ME	HT	SM	UMM
istat	Print Indoor(s) internal parameters and statuses	✓	✓	✓	✓	✓
istat2	Print istat of Daikin Indoors + their Ainet Addresses	✓				
istata	Print istat of Daikin Indoors by ascending order of their Ainet Address	✓				

Notes:

AC specific internal parameter list, supported by CoolMasterNet, can be found in [Modbus Integration Guidelines](#) document.

EXAMPLE

Query istat for all Indoor Units (DK)

```

>istat
X1.001 Other      OFF S:24.6 L:23.1 G:22.4 T:26 EV:0000 T_ON:0 OK
X1.002 Other      OFF S:25.6 L:23.4 G:23.0 T:26 EV:0000 T_ON:0 OK
X1.003 FXYM       OFF S:25.6 L:25.4 G:24.8 T:25 EV:0000 T_ON:0 OK
OK

```

Query istat for Indoor Unit L1.001 (ME)

```
>istat x1.001
X1.001 F/P OFF Heat TO:24.0 TH1: 21.0 TH2: 22.1 TH3: 22.4 SH: 0.0 SC:-22.1 Li: 70
OK
```

Query istat for all Indoor Units on the line L1 (ME)

```
>istat x1
X1.001 F/P OFF Heat TO:24.0 TH1: 21.0 TH2: 22.1 TH3: 22.4 SH: 0.0 SC:-22.1 Li: 70
X1.002 F/P OFF Cool TO:22.0 TH1: 23.0 TH2: 20.9 TH3: 21.3 SH: 0.4 SC:-20.9 Li: 70
OK
```

ostat

SYNOPSIS

ostat [[YID](#)]

DESCRIPTION

Print Outdoor(s) internal parameters and statuses. All parameters and statuses are AC system specific.

Command	Operation	Compatibility			
		DK	ME	HT	SM
ostat	Print Outdoor(s) internal parameters and statuses	✓	✓	✓	✓

Notes:

AC system specific Outdoor(s) internal parameter list, supported by CoolMasterNet, can be found in [Modbus Integration Guidelines](#) document.

EXAMPLE

Query ostat for all Outdoor Units (ME)

```
>ostat
Y1.051 PUMY-P100-140Y/VHM/36-48NHMU TH3: 22.26 TH4: 32.30 TH6: 23.45 TH7: 21.87 TH8: 70.29 63HS: 14.37
Vdc: 564.0 Ii: 0.0 Ic: 0.7 F(Hz): 0 FAN: 0 Pdm: 15.00 ETm: 18.00 SC: 0.78 SCm: 5.00 LEV1: 70 LEV2: 70
LEV3: 70 LEV4: 70
OK
```